



Direct to Load Assembly Diagram

22 Gallon, 40 Gallon, and 55 Gallon Buffer Tanks

HCT-R2-D, HCT-R4-D, & HCT-R5-D


Tools Required

Thread sealant [included]

Pipe wrench/adjustable wrench

Socket wrench with extension and 7/8" socket (to install thermowell)

Square drive installation tool (to install plugs) [included]



1. HCT-R2 20 Gallon buffer tank does not have a thermowell port.



Direct to Load Assembly Diagram

80 Gallon, and 119 Gallon Buffer Tanks

HCT-R8-D & HCT-R9-D

Tools Required

Thread sealant [included]

Pipe wrench/adjustable wrench

Socket wrench with extension and 7/8" socket (to install thermowell)

Square drive installation tool (to install plugs) [included]



Vacuum Breaker, 1/2" MPT [4695]



Bushing, 2" MPT X 1/2" FPT [SFB82]




Cross, 2" FPT [SFCR8]



Bushing, 2" MPT X 1-1/4" FPT [SFB85]



Nipple, 1-1/4" MPT X 5" Long [SFN5X05]



Direct to Load Piping Diagram

